Easidose Multi-Surface Cleaner & Degreaser





Easily removes dirt and grease from hard surfaces. Fragrance-free formulation, ideal for use in food preparation areas.

A highly concentrated and economical hard surface cleaner and degreaser. Its highly effective formulation allows for easy cleaning of most non-porous hard surfaces, including stainless steel worktops, exterior areas of kitchen equipment, canopy hoods, hobs, sinks and floors. Ideal for use via a trigger spray or mop application. Helping to remove surface grease and grime with ease, leaving no scent behind, making it suitable for use in food preparation areas.



3 x 1L | ED2/1L



6 x 750ml HDR | EVOESD-2-RF-6X750

Directions for use

For professional use only.

- 1. Always dilute before use.
- Fill 750ml refill flask to the fill line with clean, fresh water. Dispense 5-20ml product (0.6-2.7%) depending on level of soiling into the flask and lightly shake to mix.
 For use via a mop and bucket, dilute 10-20ml (1-2%) per L water.
- 3. Apply product directly to the surface or onto a cloth and wipe, paying particular attention to edges and corners.
- 4. Ensure that the surface is completely wet after application.
- 5. Leave for up to 1-2 minutes before rinsing or allow to air dry.

Refilling from 1L bottle system:

- 1. Remove the cap from the bottle and gently squeeze to fill the built in measuring cup.
- 2. After measuring, carefully pour the measured dose into a refill flask.
- 3. Fill to the line with clean, fresh water.
- 4. Re-attach the trigger spray and lightly shake the mixture, to ensure that it is fully diluted and ready for use.

Product Info

Colour: Yellow

Fragrance: None

pH: 9 - 10

Shelf Life: 24 Month



Tel: +44(0) 1295 251 721

Email: sales@cleenol.co.uk