

Evolution EV11/X2 Perfumed Antibacterial Multi-Surface Cleaner

4-in-1 product –
cleans, descales,
deodorises and
sanitises in one
action.

Effective against
99.999% bacteria
in 5 mins.

Fresh citrus scent
to help dispel
malodours.

A highly concentrated and economical acidic, disinfectant cleaner. It's highly effective formulation containing plant-based acids allows for easy cleaning and disinfection of most non-porous hard surfaces, including worktops, sinks and floors. Helping to remove surface grime as well as scale with ease. Its fresh citrus scent helps to remove malodours that may be present in the room.

Not suitable for use on acid sensitive surfaces such as marble, or for use in food preparation areas.

Directions for use

For professional use only.

1. Apply product directly to the surface or onto a cloth and wipe, paying particular attention to edges and corners.
2. Ensure that the surface is completely wet after application.
3. Leave for up to 5 mins before rinsing or allow to air dry.

Replacing the 325ml cartridges:

1. Insert the cartridge of the concentrate into the rear of the X2 trigger by pushing it straight up. Turn the locking lever into place.
2. Take the empty water cartridge and fill with clean, fresh water.
3. Line the water cartridge up with the grooves in the concentrate cartridge and push up into the front part of the trigger. Turn the locking lever into place.

X2
SPRAY SYSTEM



4 x 325ml | EV11/X2



1 x 325ml | EV/X2START

Product Info

Colour: **Purple**

Fragrance: **Citrus**

pH: **1 – 2**

Shelf Life: **24 Months**

CLEENOL

Tel: +44(0) 1295 251 721

Email: sales@cleenol.co.uk

Neville House, Beaumont Road, Banbury, Oxon. OX16 1RB.

Cleenol Group Ltd is a limited company registered in England and Wales under CRN 00635803.

Efficacy Summary

Bacteria

EN TEST	DILUTION (%)	CONTACT TIME	CONDITION	ORGANISM	
EN 1276	N/A	5 mins	Clean	Pseudomonas aeruginosa Staphylococcus aureus	Escherichia coli Enterococcus hirae

Use biocides safely and sustainably. Always read the label and product information before use.