

Steritec Vet Virucidal Cleaner



Effective against
bacteria, yeasts
and enveloped
viruses in 60
seconds.

Effective against
non-enveloped
viruses in 60
minutes.

DEFRA Approved
for General Orders
when diluted 1:9.



2 x 5L | STE-VET-CON-2X5

A highly concentrated disinfectant, suitable for use on most non-porous hard surfaces. Offers excellent broad-spectrum activity against bacteria, yeasts, fungi and viruses. Ideal for use in veterinary practices, kennels, catteries and agricultural areas.

Directions for use

For professional use only.

1. Ensure that the surface is clean and free of debris before application.
Always dilute before use.
2. For efficacy against Enveloped Viruses, dilute 45ml of product with clean water into a 750ml trigger spray (6%).
Additional dilution rates and contact times can be found on the next page, depending on efficacy required.
3. Apply to surface to be cleaned via spray or by wiping, paying particular attention to corners and under edges.
4. Ensure that the surface is completely wet after application.
5. Leave for up to 30 minutes (6% dilution) before rinsing or allow to air dry.

Directions for use – DEFRA Disinfectant (General Orders only):

1. Dilute 1 part product to 9 parts water (100ml product per 1L solution made).
2. Apply to the surface to be cleaned.
3. Leave to air dry.



6 x 750ml HDR |
STE-VET-RF-6X750

Product Info

Colour: **Purple**

Fragrance: **None**

pH: **12.5 – 13.5**

Shelf Life: **36 Months**

CLEENOL

Tel: +44(0) 1295 251 721

Email: sales@cleenol.co.uk

Neville House, Beaumont Road, Banbury, Oxon. OX16 1RB.

Cleenol Group Ltd is a limited company registered in England and Wales under CRN 00635803.

Efficacy Summary

Bacteria

EN TEST	DILUTION (%)	CONTACT TIME	CONDITION	ORGANISM	
EN 13727	2%	60 seconds	Dirty	Pseudomonas aeruginosa Staphylococcus aureus	Escherichia coli Enterococcus hirae
EN 16615	1%	60 seconds	Dirty	Pseudomonas aeruginosa Staphylococcus aureus	Enterococcus hirae Proteus hauseri
EN 1656	1%	5 mins	Clean	Pseudomonas aeruginosa Staphylococcus aureus	Enterococcus hirae Proteus hauseri
EN 14349	3%	5 mins	Clean	Pseudomonas aeruginosa Staphylococcus aureus	Enterococcus hirae Proteus hauseri

Viruses

EN TEST	DILUTION (%)	CONTACT TIME	CONDITION	ORGANISM	
EN 14476	4%	60 seconds	Clean	Modified Vaccinia virus ankara	Bovine Corona virus
EN 14476	3%	5 mins	Clean	Murine Norovirus Influenza A (H1N1/H7N9)	Adenovirus
EN 14476	5%	5 mins	Dirty	Murine Norovirus	Adenovirus
EN 14476	5%	60 mins	Dirty	Poliovirus	
EN 16777	4%	60 seconds	Clean	Modified Vaccinia virus ankara	
EN 16777	5%	30 mins	Clean	Murine Norovirus	Adenovirus
EN 14675	3%	30 mins	Dirty	Modified Vaccinia virus ankara	
EN 14675	6%	15 mins	Clean	Enterovirus E	
EN 17122	2%	5 mins	Clean	Feline coronavirus	

Fungi

EN TEST	DILUTION (%)	CONTACT TIME	CONDITION	ORGANISM	
EN 16615	2%	15 mins	Clean	Aspergillus brasiliensis	
EN 1650	4%	30 mins	Clean	Aspergillus brasiliensis	

Yeasts

EN TEST	DILUTION (%)	CONTACT TIME	CONDITION	ORGANISM	
EN 1657	2%	5 mins	Clean	Candida albicans	
EN 13624	4%	60 seconds	Dirty	Candida albicans	
EN 16615	1%	60 seconds	Dirty	Candida albicans	
EN 16438	2%	15 mins	Clean	Candida albicans	

Use biocides safely and sustainably. Always read the label and product information before use.

CLEENOL

Tel: +44(0) 1295 251 721

Email: sales@cleenol.co.uk

Neville House, Beaumont Road, Banbury, Oxon. OX16 1RB.

Cleenol Group Ltd is a limited company registered in England and Wales under CRN 00635803.