
Easidose Antibacterial MultiSurface Cleaner





Effective against 99.999% bacteria in 30 seconds.

Fragrance- free formulation, ideal for use in food preparation areas.

A highly concentrated and economical disinfectant cleaner. Its highly effective formulation allows for easy cleaning and disinfection of most non-porous hard surfaces. Its fragrance-free formulation makes it ideal for use in food preparation areas, including on worktops, microwaves, chopping boards and stainless steel surfaces.

Directions for use

For professional use only.

- 1. Always dilute before use.
- 2. Fill 750ml refill flask to the fill line with clean, fresh water. Dispense 20ml product (2.7%) into the flask and lightly shake to mix.
- Apply product directly to the surface or onto a cloth and wipe, paying particular attention to edges and corners.
- 4. Ensure that the surface is completely wet after application.
- Leave for up to 30 seconds before rinsing or allow to air dry.
 Surfaces that may come into contact with food must be rinsed after application

Refilling from 1L bottle system:

- 1. Remove the cap from the bottle and gently squeeze to fill the built in measuring cup.
- 2. After measuring, carefully pour the measured dose into a refill flask.
- 3. Fill to the line with clean, fresh water.
- 4. Re-attach the trigger spray and lightly shake the mixture, to ensure that it is fully diluted and ready for use.



3 x 1L | ED3/1L



6 x 750ml HDR | EVOESD-3-RF-6X750

Product Info

Colour: Red

Fragrance: None

pH: **9.5 - 11.4**

Shelf Life: 24 Months



Efficacy Summary

Bacteria

EN TEST	DILUTION (%)	CONTACT TIME	CONDITION	ORGANISM	
EN 1276	2.7%	30 seconds	Clean	Pseudomonas aeruginosa Staphylococcus aureus	Escherichia coli Enterococcus hirae

Use biocides safely and sustainably. Always read the label and product information before use.

